




FP-37 R





FP-37 R

FP - 37 R	
Pozice	Kód
1	504503050
2	504503010
3	504503040
4	454500380
5	454500480
6	504500260
7	454500580
8	401051001
9	401031001
10	450503500
11	407600100
12	407502120
13	407502120
14	454500400
15	407810000
16	407502115
17	407502121
18	407860008
19	401600120
20	401600110
21	454500440
22	500113500
23	407502116
24	402503000
25	401550010
26	402595001
27	402593000
28	402590770
29	401500556
30	401515210
31	401515100

Exploded view

TABLE A: LABELS

MODEL	CODE	NOTE
VT	402594273	
TO - 940	402594234	Switch
TO - 940	402594235	Timer
TO - 960	402594234	Switch
TO - 960	402594235	Timer
TO - 920	402594233	Switch
TO - 920	402594235	Timer
TO - 930	402594233	Switch
TO - 930	402594235	Timer
VEC	402594241	
PM - LTF	402594244	
KD	402594243	
FP - 36	402594237	
FP - 66		
FP - 37		
FP - 67		
FT	402594247	
PD		
PM		
PS		
FP - 38		
FP - 68		
FE	402594272	
BM	402594236	
BMV		
HD		
WE		
WEV		
OTS		
UH		
BM-D	402594271	
SE		
CW		
GV		

